



ADDITIONAL RUNWAY INFORMATION

RWY		USABLE LENGTHS			
		Threshold	Landing Beyond Glide Slope	TAKE-OFF	WIDTH
09	HIRL PAPI-L (angle 3.0°)	① 5305' 1617m		5735' 1748m	148' 45m
27	HIRL	① 4724' 1440m			

① Last 492' 150m not available for landing.

TAKE-OFF & DEPARTURE PROCEDURE

AIR CARRIER (JAA)		AIR CARRIER (FAR 121)	
LVP must be in force ALL Rwys RCLM (Day only) or RL	All Rwys RCLM (Day only) or RL	All Rwys Adequate Vis Ref	
A	400m	2 Eng	400m
B		3 & 4 Eng	
C			
D			

DEPARTURE PROCEDURE: To join A324 southbound: Climb to west to intercept FOF VOR R-195 direct to SV NDB. Remain clear of clouds and in sight of surface until passing 4200'. To join A324 northbound: Climb north. Remain clear of clouds

and in sight of surface until passing 2000'. To join G642: Climb north to join G642 from the north. Remain clear of clouds and in sight of surface until passing 3250'.